

EZCOMMAND[®] DYNAMIS[®]

Dynamis Digital trainset set up - please read before using your trainset

Thank you for your choice of the Bachmann Branchline Dynamis Digital Trainset. Please take a few moments to familiarise yourself with the system. Please also refer to the enclosed general train set User Guide, although some set contents may differ.

Step 1: Getting Started


Connect the Basestation to power supply. Insert batteries into handset and turn on. Press the Stop Key if the indicator is 'ON'. The IR Receiver LEDs will flash for a few seconds as connection is made.

From now, your train has a default address of 3, Dynamis powers on ready to operate a train with an address of 3.

Dynamis has a context menu. A list of the meanings of each item is shown overleaf.

Step 2: Turning the headlights on

Press headlight key to turn headlights ON/OFF




Step 3: Changing the address of your train

Each digital train has an address - a number between 1 and 9999 - that it will respond to. The address can be changed as often as desired, but when carrying out this procedure the train being addressed must be the only train on the track connected to the Dynamis.

Use WRITE ADDRESS ON SERVICE TRACK option in the Program menu

press *MENU* [SCROLL] *PROGRAM* [SCROLL] *WRITE ADDR ON SERVICE TRACK*

Use  to delete existing address then, enter the new address and press [PROG]

The train will move momentarily during programming.

Step 4. Changing the handset roster information

To change the name press - *MENU* *EDIT NAME* Use  to delete default name


Enter a new name eg *CLASS 150 DMU* using the keypad

To change the Icon press - *MENU* [SCROLL] *EDIT SYMBOL* choose one of the icons, or none.


Step 5. Running another train

Press [LOCO] and enter the address of the loco / train to be run.

If there is already a roster entry this will be shown, otherwise a new roster record is created with the default name of 'Locomotive X' where X was the address entered. This can be changed to be a more representative name (step 3 on left).




Handset features



The tape under the Basestation should only be removed to expand the system with the separately available ProBox.

Screen Reference



Full instructions for the use of Dynamis are contained in the accompanying User Guide

Action key icons	Description of action	Description of key in User Guide
	Add loco to / remove from Consist	[CONSIST]
	Select locomotive by address	[LOCO]
	Turnout / accessory operation - turnouts left / right or accessories on / off	[DIVERGE] or [STRAIGHT]
	Access the menu	[MENU]
	Accept Cancel	[ACCEPT] [CANCEL]
	Scroll left or right	[SCROLL]
	Move between CV selection and value for CV in the programming menus	[CV<>] [<>VALUE]
	Write value to CV / read from CV	[READ] [PROG]
	Backspace in text entry	[BKSP]